



Africote – Division of Union Flooring Tiles (Pty) LTD
VAT: 4790102968 Reg no: 1965/005479/07
Unit 22 Sunview Centre
7 North Reef road
Bedfordview
P.O Box 357
Bedfordview,2008
South Africa
011 201 7300

Amended oct 2019

DATA SHEET- PLATINUM SHEEN PURE ACRYLIC PAINT

DESCRIPTION:

Africote Platinum Sheen is a high-quality medium-sheen pure acrylic paint designed to give a smooth finish with the following advantages:

Exterior and Interior application. UV Resistance. Good stretch properties. Very low dirt retention. Excellent scrub resistance and washability.

PREPARATION ON VARIOUS SURFACES:

MAKE SURE SUBSTRATE/SURFACE IS FREE OF GREASE, OIL, DIRT AND DUST.

RAW PLASTER AND BRICKS: Platinum Sheen will have excellent adhesion to these surfaces provided they are well-cured, clean, sound, new plaster must be at least 28 days old.

TREATMENT OF POWDERY AND FLAKY SURFACES

Remove all loose materials via scraping, wire brush etc. Apply a one coat Africote Bonding Liquid.

SURFACES TREATED WITH GYPSUM (Rhino lite)

Apply 1 coat of Africote Plaster Primer to manufacturer's instructions.

RAW PLASTER AND BRICKS

Apply 1 coat of Africote Plaster Primer to manufacturer's instructions.

For Coastal and high moisture areas use Africote Plaster Primer as the first coat on raw plaster.

PLASTER WITH CHASE AND PATCH MARKS.

If the surface is not properly prepared the chase and patch marks will mirror through, when painted. Apply Africote Fillercrack and spot prime with Africote Plaster primer.

SURFACES PREVIOUSLY PAINTED WITH WATER BASED PAINTS:

If the paint is relatively new and still clean, the surface must be well dusted by wiping with a clean damp cloth. If the surface shows any sign of dirt or contamination, it should be scrubbed clean with Africote Anti-fungal wash. Surface must be clean and dry prior to painting. Old powdery PVA surfaces that are still sound must be thoroughly sanded and then wiped clean with a damp cloth as a minimum treatment.

Alternatively, sand lightly, remove dust, spot prime with 1 coat of Africote Bonding liquid.

APPLICATION OF AFRICOTE PLATINUM SHEEN:

Thoroughly mix the contents of the bucket prior to application. Apply Africote Platinum Sheen with a good quality sheepskin roller or paintbrush.

Allow at least 6 hours at 23 degrees before over coating. Drying times will be extended during cold, wet, or humid conditions. Do not apply during cold (10 degrees or wet weather)

DISCLAIMER:

For best colour and sheen consistency, it is highly recommended to use the same batch number. As batches may differ from final colour appearance ie: sheen, texture, colour and light reflections, application, surface texture and preparation. When doing any type of touch up work, paint corner to corner Africote will not entertain any claims otherwise.

Unit 22 Sunview Centre, 7 North Reef Road, Bedfordview, P.O Box 357 Bedfordview,2008, South Africa
Directors: **Colin John Reeves; Roberto Paulo Ghisleni; Gary John Shayne; Wayne Gregory Koonin.**
VISIT OUR WEBSITE AT: www.africote.co.za