



Amended April 2022

DATA SHEET - EGGSHELL ENAMEL PAINT

Description:

Africote low gloss satin enamel is a high-quality interior /exterior enamel for surfaces where an eggshell durable finish is required for trims, doors windows and inside walls.

Surface Preparation:

Ensure surface is dry and in sound condition, free from dust, grease, oil, algae, fungus, or any loose particles.

Unpainted Surfaces:

Cement Plaster – prime with one coat Africote Plaster Primer followed by one coat of Africote Universal Undercoat. Apply 2 coats eggshell enamel.

New Metal – prime with one coat of Africote QD red oxide primer. Followed by 2 coats eggshell enamel.

Rusted Metal – apply Africote Rust Converter as per manufacturer's instructions. Prime with one coat QD Etch Primer followed by one coat Africote Universal Undercoat. Followed by 2 coats Eggshell enamel.

Wood – prime with two coats Africote Universal Undercoat. Followed by 2 coats eggshell enamel.

Previously painted surfaces:

Remove all dirt and all flaking paint.

Gloss & Enamel paints – sand well, clean and apply one coat of Africote Universal Undercoat. Followed 2 coats eggshell enamel.

Waterbased paints – clean well and apply 2 coats of Africote Eggshell enamel.

Chalky surfaces – wipe surface and apply 1 coat of Africote Bonding Liquid, depending on severity of condition. Followed by 2 coats eggshell enamel.

Poor condition surfaces – strip down and treat as new surface.

Application:

1. Stir well and apply first coat un thinned.
2. Stir well and apply second coat after 16 hours drying time.

Caution:

1. Application must be even to avoid variation in finish.
2. Spot touch-ups will lead to variation in finish and colour.
3. Applying coats too thick can cause wrinkling and running.
4. Very cold conditions will extend drying times.

SPECIFICATION:

Use: Interior

Appearance: Eggshell (Satin) Finish

Drying Time: 16 hours

Recoat Time: 16 hours

Spread Rate: 10 – 12sq m/ Litre

Cleaning: Mineral Turpentine

Thinning: Not recommended

Health and Safety:

1. Keep out of reach of children.
2. Avoid swallowing. If swallowed, induce vomiting, and seek medical attention immediately.
3. Avoid eye contact. In case of eye contact, rinse eyes thoroughly with water, seek medical attention immediately.
4. Allow sufficient ventilation during application.

NB: **No** claims will be entertained where applications are done using other manufacturers products in combination with Africote products. This includes bonding liquids, filler coats, sealers, undercoats etc.

NB: Due to ongoing research and development undertaken on our coatings and the application process, coupled with technological advances in the industry, please consult our factory to ensure you have the latest Data Sheet.
